



LIGHT KIT OWNER'S MANUAL

Model No.: FLG-1200-xxx

All electrical connections must be in accordance with local codes, ordinances, or national codes. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified electrician. Before starting installation, disconnect the power by turning off the circuit breaker or removing the fuse at fuse block. Turning power off using fan switch (speed control on/off) is not sufficient to prevent electrical shock.

NOTE: The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors which cannot be built into any product. These factors must be supplied by the person (s) caring for and operating the unit.

Attention: The Energy Policy Act of 2005 requires this light kit to be equipped with a 190 watt limiting device. If lamping exceeds 190 watts, the ceiling fan's light kit will shut off automatically.

1. Remove and discard the finial from the switch housing.
2. Attach the light kit to the switch housing by feeding the light kit wires (black and white) through the hole of switch housing and then screw it onto the switch housing by nut & lock washer. Be sure it is tight enough to prevent light kit from vibrating loose. (Fig. 1)
3. Locate the terminal block in the switch housing for light wire connection; loose the screws on the terminal block, insert the light wire to each terminal block and re-tighten the screws loosened previously, make sure the white wire from the light kit connected to the white wire from switch housing, and black wire from light kit connected to the blue wire from switch housing.
4. While holding the light kit assembly under your fan, snap together the wire connection plugs.
5. Carefully push all wires back into the switch housing, then install the light kit assembly onto the mounting plate with 4 screws provided. Be sure to tighten all screws. (Fig. 2)
6. With the power off, insert the halogen bulbs (included) into the light kit sockets. Max. 50 watts.
Note: Lamping in excess of 190 Watt will disable your light kit. To reset your light kit you must turn the power off and re-lamp keeping the wattage under 190 watts.
7. Raise the glass shade up against the light kit, Place the metal plate with rubber on the top over the stem and turn it clockwise until it locks up against the glass shade. Do not overtighten. (Fig. 3)
8. Raise the glass shade to the light kit and secure tightly with the glass cover and decorative nut provided.

